

ITEM NO. :T7269-2CU

ASSEMBLY INSTRUCTIONS

1. Attach the frame (B) to the screw on the lamp body (A) using the nut (C) to secure.
2. Attach the fabric shade (D) to the screw on the lamp body (A) using the nut (E) to secure.

