

# ITEM NO. : T5379-3DU

## ASSEMBLY INSTRUCTIONS

- 1.Screw the connecting rod (B) into the joint connector nut on the lamp body (A) using the nut to secure.
- 2.Screw the bulb (C) into the lamp holder.
- 3.Adjust the position of the nut on the the connecting rod (B). Put the silicone spacer (D) , the glass sheet (E), and the metal cover (F) around the connecting rod (B) one by one in order. The glass sheet should be placed at the bottom of the lampshade using the nut (G) to secure.
- 4.Screw the connecting rod (H) into the joint connector nut (G).
- 5.Put the iron frame (J) around the connecting rod (H). Insert the iron rods on the frame into the holes on the lamp body (A) using the nut (K) to secure.

*Please consult a qualified Electrician if you are not familiar with electrical wiring.*

