## ITEM NO. :T5304DU-C-N

## ASSEMBLY INSTRUCTIONS

1. Attach the lamp holder (A) to the lampshade (B) using the nut (C) to secure.

2.Drill holes on the wall according to the size of plastic drywall anchor and gently tap the plastic drywall anchor (D) into the hole.

3.Screw the hook (E) into the plastic drywall anchor.

4.Wrap the wires around the hook on the 8-shaped fastener (F) and hang the 8-shaped fastener (F) to the hook (E).

5.Screw the bulb (G) into the lamp holder.

6.Screw the lampshade (H) into the lamp holder gently.

Please consult a qualified Electrician if you are not familiar with electrical wiring.

